

select tabouret de bar 11-373

Werner Max Moser, 1934

Sitz gepolstert, Sitzrahmen und Füsse aus gebogenem Massivholz, Fussring Stahlrohr verchromt B39, H81

Werner Max Moser, 1934

Assise rembourrée, cadre du siège et pieds en bois massif cintré, repose-pieds en acier chromé.
L39, H81

Werner Max Moser, 1934

Upholstered seat, seat frame and legs of solid bentwood, chrome-plated connection ring
W39, H81

Varianten / variantes / variants



Select
11-370

Technische Angaben / specifications / specifications

Masse / mesure / measure



Gewicht / ponds / weight 4.0 kg 8.0 lb

Polsterung / rembourrage / upholstery ja / oui / yes

select tabouret de bar 11-373

Holzarten / types de bois / types of wood

Belag / revêtement / surface



Hêtre naturel BN 000 AM
Buche natur BN 000 AM
Beech natural BN 000 AM



Hêtre noir BB 203 SG
Buche schwarz BB 203 SG
Beech black BB 203 SG



Chêne naturel EN 000 AM
Eiche natur EN 000 AM
Oak natural EN 000 AM



Hêtre anthracite BB 200 SG
Buche anthrazit BB 200 SG
Beech anthracite BB 200 SG



Hêtre teinté blanc BG 172 SG
Buche geweisst BG 172 SG
Beech whitewashed BG 172 SG



Chêne chêne fumée EB 535 AM
Eiche Räuchereiche EB 535 AM
Oak smoked oak EB 535 AM



Hêtre teinté ebony BB 100 SG
Buche Ebony BB 100 SG
Beech ebony BB 100 SG



Hêtre teinté noyer BB 151 SG
Buche Nuss BB 151 SG
Beech walnut BB 151 SG